

## KEY NOTES

- 1. PROVIDE VIEW WINDOW OVER SCRUB SINK LOCATION.
- AN ELECTRONIC FAUCET IS OPTIONAL.
  ALL CABINETS SHALL BE STAINLESS STEEL.

## General Notes:

- For typical equipment mounting heights see "TYPICAL EQUIPMENT MOUNTING HEIGHTS" drawing.
- 2. MIL—STD—1691 data can only be accessed from the Equipment Plan.

## OPERATING ROOM, SUBSTERILE/SCRUB (ORSR1/ORSA1)

SURGERY (INPATIENT & AMBULATORY) 20.44 NSM (220 NSF) 0 ELEVATIONS 1000 2000 DATE: 01/28/2002 1:50 SCALE (MILLIMETERS)